

ΓΕΝΙΚΕΣ ΟΔΗΓΙΕΣ

GENERAL INSTRUCTIONS

1. Χρησιμοποιούνται για άντληση καθαρών και ελαφρός ακαθάρτων.

2. Πριν από την εκκίνηση της αντλίας γεμίστε τους σωλήνες με το υγρό που πρόκειται να αντλήσει.

3. Κάθε δύο μήνες βάλτε λάδι στα κουζινέτα και γράσο στα ρουλεμάν όπου υπάρχει.

4. Φροντίσατε για την απόλυτη ευθυγράμμιση αντλίας και κινητήρα (κεντράρισμα).

5. Ο στυπιοθλίπτης πρέπει να ρυθμιστεί έτσι, που να στάζει όταν λειτουργεί η αντλία όπου υπάρχει.

6. Η αντλία δεν πρέπει να λειτουργεί «εν ξηρώ».

7. Ελέγξατε την σωστή φορά περιστροφής.

8. Περιοδικά περιστρέψατε τον άξονα της αντλίας από το κόμπλερ, για να μην κολλήσει σε περίπτωση ακινησίας για μεγάλο χρονικό διάστημα.

1. To be used only for pumping of clean and light impure liquids.

2. Before the departure of pump fill the pump with the liquid to be pumped.

3. Grease the ball bearings where it exists and lubricate the thrust bearings every two months.

4. Center carefully the pump and the motor.

5. The stuffing must be regulated so that it should be dripping when the pump is in operation where it exists.

6. The pump should not be operated “dry”.

7. Check that the pump is rotating at the correct way.

8. Periodically rotate the shaft (when the pump is out of operation for prolonged period of time) in order to avoid the bore of the coupling to be stuck on the shaft.